















BY OGGI FURNITURE


ASSEMBLING INSTRUCTION

SHIRO RSG 5DK

WHITE - TUSCANY OAK




<p>011402</p>  <p>12 X</p>	<p>010501</p>  <p>26 X</p>	<p>100901</p>  <p>2 X</p>	<p>020101</p>  <p>10 X</p>	<p>011002</p>  <p>12 g</p>	<p>090701</p>  <p>5 X</p>
<p>060210</p>  <p>5 X</p>	<p>030201</p>  <p>5 X</p>	<p>011704</p>  <p>Ø6 X 1/2" 25 X</p>	<p>011707</p>  <p>Ø6 X 5/8" 12 X</p>		




 X 2  ±60 M

1




2




05

3









4




06

5




<p>090701</p>  <p>5 X</p>	<p>060210</p>  <p>5 X</p>	<p>030201</p>  <p>5 X</p>
<p>011002</p>  <p>12 g 06 X 1/2"</p>		<p>011704</p>  <p>25 X</p>

7



6



07

08