


















ASSEMBLING INSTRUCTION



SHIRO SIDEBOARD 80

WHITE - TUSCANY OAK



<p>010501</p>  <p>30 X</p>	<p>011402</p>  <p>12 X Ø10 MM X 1 3/4"</p>	<p>011601</p>  <p>4 X Ø6 MM X 1 1/2"</p>	<p>010801</p>  <p>4 X</p>	<p>010701</p>  <p>4 X</p>	<p>011002</p>  <p>12 gr</p>
<p>011707</p>  <p>16 X Ø6 X 5/8"</p>	<p>100905</p>  <p>2 X</p>	<p>100901</p>  <p>2 X</p>	<p>011704</p>  <p>16 X Ø6 X 1/2"</p>	<p>020305</p>  <p>4 X</p>	<p>060136</p>  <p>2 X</p>




 X 1 ± 60 M 

010701



4 X

011601



4 X


010501




4 X

∅6 MM X 1 1/2"

1



2




05

010501



21 X

011402



12 X


011707



∅6 X 5/8"


16 X

100905



2 X

100901




2 X

8

9

3

4



06

010501



5 X

010801



4 X


Ø6 X 1/2"

011704




16 X

020305




4 X

060136




2 X

011002




12 gr


5




7



6



8



07

08