


















ASSEMBLING INSTRUCTION



SHIRO RSG 4DK
WHITE - TUSCANY OAK




<p>011402</p>  <p>12 X</p>	<p>010501</p>  <p>22 X</p>	<p>100901</p>  <p>2 X</p>	<p>020101</p>  <p>8 X</p>	<p>011002</p>  <p>12 g</p>	<p>090701</p>  <p>4 X</p>
<p>060210</p>  <p>4 X</p>	<p>030201</p>  <p>4 X</p>	<p>011704</p>  <p>20 X Ø6 X 1/2"</p>	<p>011707</p>  <p>12 X Ø6 X 5/8"</p>		









 X 2  ±60 M




5




<p>090701</p>  <p>4 X</p>	<p>060210</p>   <p>4 X</p>	<p>030201</p>  <p>4 X</p>
<p>011002</p>  <p>12 g 06 X 1/2"</p>		<p>011704</p>  <p>20 X</p>

7



6



07

08